

POLYCOAT

USE:

Sealer for porous models. Also, use as a semi-permanent release agent on porous or non-porous models. Polyurethane rubber moulds with PolyCoat imitate silicone rubber moulds. Do not pour liquid silicone rubber on surfaces coated with PolyCoat.

DIRECTIONS:

Brush or spray 3 thin coats on surface. Allow to dry 10 minutes between coats. Let final coat dry for 30 minutes in warm area or under heat lamp.

CONTENTS:

Aliphatic hydrocarbon.

WARNING:

FLAMMABLE LIQUID AND VAPOUR. MAY CAUSE ALLERGIC RESPIRATORY AND/OR SKIN REACTION. HARMFUL IF INHALED. MAY CAUSE EYE AND SKIN IRRITATION.

Keep away from heat, sparks and flame. Do not breathe vapours. Keep container closed. Use only with adequate ventilation. Avoid contact with eyes, skin and clothing. Wash thoroughly after handling. First Aid: If inhaled, remove to fresh air and get medical attention if symptoms occur. In case of eye contact, flush eyes with plenty of water and see a doctor. In case of skin contact, wash with soap and water. In case of spill, extinguish sources of ignition, don personal protective equipment, absorb spill with inert material, then place in suitable container. Dispose of in accordance with all regulations.